
## **RE 199**

## ELECTRONIC CARD TO CONNECT TO AN INVERTER , OR OTHER ELECTRODE WELDER , TO OTHER FUNCTION AND COMMAND FOR TIG WELD.



## **FUNCTION:**

- -Pregas, up slope, weld current, slope down, post gas.
- -Local or remote control.
- -Selecting electrode, tig with HF, tig with lift-arc, weld-mode.
- -Relays to HF command, gas valve command, voltage booster command.
- -Torch bottom working in normal mode or latching mode.

